

## Connect line/Wired Tracker general ins

SMS Command	Reply
password123456 666888	password ok
101#136*****#	OK
102#136*****#	OK
103#136*****#	OK
D101#	OK
D102#	OK
D103#	OK
C10#	101# 102# 103#
125#	OK
126#	OK
vibtime123456,n	vibtime set ok
G1234	
SF	SF OK
CF	CF OK
CQGPS	GPS reset OK!
CQ	system reset OK!
FORMAT	OK
CXZT	
FREQ,123456,30	OK
STATIC,123456,40	OK
sleep,123456,10	OK
zone123456 e08	OK
109#	OK
tmod,123456,5	OK

## Instruction (tianqin protocol password default 123456, ministry

Modify the owner password instruction, the password is 6 pure digits (the default owner password is: 123456, for example, change to 666888 new password)
The first specific number, which is the same as the "owner number"
102 is the first SOS specific number
103 is the second SOS specific number
D101# removes the first number
D102# means delete the second number
D103# indicates the deletion of the third number
Query specific number
Turn on vibration SMS alarm
Turn off vibration SMS alarm
Set the vibration alarm duration SMS instruction, 1-15 seconds n(0~15),0 to cancel the vibration alarm, the default is 3 seconds, that is, vibration lasts 3 seconds alarm
Reply to Google links
SMS fortification
SMS removal
GPS restart
Equipment to restart
factory data reset
"Query device status Reply: device software version, ID, IP, power, working mode: M is single, A is automatic, C is continuous, signal quality"
ACC ON upload interval 30 means 30 seconds
ACC OFF upload interval 40 means 40 seconds
Open hibernation 10: indicates 10 minutes; 0: indicates no hibernation
Change time zone E08: indicates zone 8
Switch between Chinese and English
ntelligent working mode 5 means waking up once every 5 minutes